



TRI-TRAN™ RECEIVER INSTALLATION INSTRUCTIONS

Part No. 62851

Thank you for purchasing the B&D Tri-Tran™ plug in two channel Receiver. Familiarise yourself with the following instructions prior to commencing set up. Store this information in a safe place for future reference. The B&D Tri-Tran™ receiver has transistors on board which provide an open collector contact for controlling virtually any electronic garage door or gate.

BRAND OF TRANSMITTERS

The first memory location sets the type of transmitters which can be stored into the receivers memory. It either can be B&D Tri-Tran™ or ATA TrioCode™ transmitters. For example if first transmitter stored is TrioCode™ then rest of transmitters can only be the TrioCode™ type and mixing of TrioCode™ and Tri-Tran™ is not possible. By deleting all stored transmitter codes from the receivers memory will allow you to choose either TrioCode™ or Tri-Tran™ transmitters again.

UNIVERSAL PROGRAMMER

A B&D Universal Programmer can be used to set timer (adjustable from 0.00 to 655.34 seconds), Edit, back up / restore transmitters.

STORING TRANSMITTER CODE

1. Press and hold SW1 (for channel 1) or SW2 (for channel 2) on the receiver board. The LED D1 will start to flash.
2. Press the transmitter button you would like to use to control the device for two seconds. The LED will start to flash faster.
3. Release the transmitter button and pause for two seconds. Press the same button again for two seconds. The LED will stay on for a second and then turns off.
4. Release SW button.
5. Press the transmitter button to test operation.

DELETING A SINGLE TRANSMITTER'S CODE

1. Press and hold SW1 (for channel 1) or SW2 (for channel 2) on the receiver board. The LED will start to flash.
2. Press the transmitter button you would like to remove from receivers memory for two seconds. The LED will start to flash faster.
3. Release the transmitter button and pause for two seconds. Press the same button again for two seconds. The LED will slowly flash two times.
4. Release SW button.
5. Press the transmitter button to confirm that it has been removed.

DELETING ALL STORED TRANSMITTER CODES




1. Turn the power off to the receiver.
2. Press and hold SW1 button.
3. While holding SW1 turn power on again. After 15 seconds the Coding LED will illuminate to indicate that the receivers memory has been cleared.
4. Release SW1. All the stored codes should now be deleted. Confirm this by pressing the transmitters previously used to operate the device. There should be no response.

COAXIAL CONNECTION

An optional coaxial antenna is available for use with the receiver in difficult reception areas. The antenna has to be mounted as high as possible so that it is not obstructed, e.g. on top of a fence, or on a wall at the front of a garage, etc. Connect the core of coaxial lead to replace the existing antenna wire (outer screw socket). Connect shield to the spare (inner) screw socket.

HARNESS

User may have to cut and strip wires to connect to different openers. Cut and leave white wire if the second channel is not used.



SPECIFICATIONS

Power Supply: 9 volts to 24 Volts DC ONLY

Frequency: Multi frequency


Memory Capacity: 250 Transmitters

Control Output 1 : Open collector output at pin one for channel one (40 dc volts 100ma max)


Control Output 2 : Open collector output at pin four for channel two (40 dc volts 100ma max)

HOW TO CONNECT RECEIVER WITH HARNESS TO OPENERS:


CONNECTING RECEIVER TO CONTROLL-A-DOOR P DIAMOND




CONNECTING RECEIVER TO CONTROLL-A-DOOR DIAMOND - POWER DRIVE




CONNECTING RECEIVER TO CONTROLL-A-DOOR 4



CONNECTING RECEIVER TO CONTROLL-A-DOOR P



CONNECTING RECEIVER TO CONTROLL-A-DOOR R



B&D Doors Office Locations:

Brisbane: 17 Oasis Court, Clontarf 4019.

Phone: (07) 3883 0200

Melbourne: 147-153 Caterbury Rd, Kilsyth 3137.

Phone: (03) 9237 7766

Sydney: 34 Marigold St, Revesby 2212.

Phone: (02) 9722 5555

Adelaide: 23 Frederick Rd, Royal Park 5014.

Phone: (08) 8440 4747

Wollongong: 13-14, Drummond St, Coniston NSW 2500

Phone: (02) 4226 2288

Perth: 96 Mulgool Rd, Malaga 6090.

Phone: (08) 9247 8777

Newcastle: Unit 1/108 Mitchell Rd, Cardiff NSW 2285

Phone: (02) 4956 8533

International/Export: 34 Marigold St, Revesby 2212.

Phone: +61 (0)2 9722 5555



Prefixed trademarks are the property of B&D Australia Pty Ltd
 B&D Doors & Openers is a division of B&D Australia Pty Ltd, an Alesco company
 ABN 25 010 473 971
 Copyright 2008 B&D Australia Pty Ltd.

An **alesco** Company

Website: www.bnd.com.au

YOUR REPRESENTATIVE IS