


Installing Receiver to Merlin P2600

- 1. TURN OFF POWER FROM THE POWER POINT**
2. View the diagram below and ensure that it matches with the back of your motor.
3. Loosen each of the two on the back of your motor.
4. Connect the black receiver cable to the top screw and tighten.
5. Connect the blue receiver cable to the bottom screw and tighten.
6. Connect the AC adapter to a power point.
7. Turn power back on and ensure the receiver powers up.
8. All of the new remotes have been pre-programmed to the receiver.
Press button 1 on your new remote to ensure it can operate the door.



Coding new remotes

Please Note: Your original remotes will continue to work

1. Press the black learn button inside the receiver located next to the LED light until the LED illuminates then release.
2. Press and hold any button on your new remote until the LED flashes.
3. The remote is now coded, please test the remote to ensure it can operate the motor.
4. If you have more than one new remote, please repeat steps 1-3.

www.remotepro.com.au

WARNING

To prevent possible SERIOUS INJURY or DEATH:
- Battery is hazardous: NEVER allow children near batteries.
- If battery is swallowed, immediately notify a doctor.
To reduce risk of fire, explosion or chemical burn:
- Replace ONLY with the same size and type battery
- DO NOT recharge, disassemble, heat above 100° C or incinerate
Battery will cause SEVERE or FATAL injuries in 2 hours or less if
swallowed or placed inside any part of the body.

