

BENINCA Brainy 24 Coding Instructions

1. Press once and immediately release the <PG> button on the control board and the screen will display "PAR".
2. Press <+> button on the control board to cycle through the menu until the screen shows "rAd".
3. Press the <PG> button on the control board once and immediately let go.
4. The screen should now display "PP". If it does not display this, please press the <+> button until the screen displays "PP" and press the button <PG> button once and immediately release.
5. The screen should now display "PUSH", once this is on the screen you must immediately press and hold the button on the new remote you would like to program into the motor.
6. If the coding has been successful "oH" will be displayed on the screen. If "Err" is displayed this generally indicates an error and the remote has not been programmed.
7. Please wait 1 to 2 minutes for the motor to exit learn mode, and then test the new remote.

