

REMOTE PRO

PROGRAMMING INSTRUCTIONS



MAGIC BUTTON

PROGRAM YOUR NEW MAGIC BUTTON REMOTE

1. Press and immediately release the Learn/Code button on your motor control panel.
2. Press and hold any button on your new remote twice.
3. Test your remote.



WARNING

This product may contain a coin/button cell battery. Keep product and batteries away from children. A battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button cell battery has been swallowed or placed inside of any part of the body.

