- 1. Push and hold both top buttons of the new Multi 4 remote together and hold these buttons until the remote constantly flashes quickly.
- 2. Release both buttons.
- 3. Place both your new remote and the original remote back to back.
- 4. Push and hold the button on your original remote you wish to copy and do not let go.
- 5. Whilst still holding the button on your original, push and hold any button on the new Multi 4 remote that you wish to learn the code.
- 6. Keep holding one button on your original and one button on the new Multi 4 remote until the new Multi 4 remote begins to flash rapidly. This step should only take a few seconds. If you are unable to get the new remote to flash rapidly please try positioning the remotes differently.
- 7. Once the new remote has copied the code, please test to ensure it can operate the door.
- 8. Press and hold the bottom two buttons until the remote flashes to exit learning mode.

WARNING!

This product may contain a coin/button cell battery. Keep product and batteries away from children. Battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button battery has been swallowed or placed inside of any part of the body.