

REMOTE PRO

PROGRAMMING INSTRUCTIONS



CLONING INSTRUCTIONS

CLONING YOUR ORIGINAL REMOTE TO YOUR NEW REMOTE

1. Push and hold both top buttons of the new Multi 4 remote together and hold these buttons until the remote constantly flashes quickly.
2. Release both buttons.
3. Place both your new remote and the original remote back-to-back.
4. Push and hold the button on your original remote you wish to copy and do not let go.
5. Whilst still holding the button on your original, push and hold any button on the new Multi 4 remote that you wish to learn the code.
6. Keep holding one button on your original and one button on the new Multi 4 remote until the new Multi 4 remote begins to flash rapidly. This step should only take a few seconds. If you are unable to get the new remote to flash rapidly, please try positioning the remotes differently.
7. Once the new remote has copied the code, please test to ensure it can operate the door.
8. Press and hold the bottom two buttons until the remote flashes to exit learning mode.

WARNING

This product may contain a coin/button cell battery. Keep product and batteries away from children. A battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button cell battery has been swallowed or placed inside of any part of the body.

