Programming your new remote to your Richmond motor

- Press and release the learn button (S1 or K4) once the LED light on the motor flashes.
- 2. While the light is on, press your desired button on your new remote for 2 seconds and release.
- 3. Press the same button on your new remote again for 2 seconds.
- Test your new remote.

WARNING

This product may contain a coin/button cell battery. Keep product and batteries away from children. A battery can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button cell battery has been swallowed or placed inside of any part of the body.



