

Erasing Individual remotes.

Defaulting.




<p>Repeat for each remote to be erased.</p>  <p>Press the button to be erased</p> <p>You must erase one remote at a time.</p> <p>20 beeps</p>	<p>Press and hold for longer than 10 Seconds. When the unit sounds a Long Beep you can stop pressing the button and then wait for it to silence.</p>  <p>This function will Default (Erase all) remotes from the units memory</p>
--	---

For more info visit our web site: www.securitydistributors.com.au Technical help : 1300 882 101

Feb 2013






Programming

Please follow the steps below to Learn in remotes to the receiver. The unit can store up to 80 remotes. When memory has reached its limit the unit will automatically exit out of program mode and sound a long beep. The unit auto exits after 10 seconds.







<p>Step 1.</p>  <p>Enters Learn mode</p>	<p>Step 2.</p>  <p>Press button twice</p>	<p>Step 3.</p> <p>Continue with Step 2 to Learn in all the remotes A Max of 80 remotes can be learnt to memory</p>	<p>Step 4.</p>  <p>Exits from Learn</p>
--	---	---	---

Programming On/Off Function

This function enables the receiver to be programmed with a button to turn the relay ON and a different button to turn the relay OFF.

<p>Step 1.</p>  <p>Enters Learn for ON/OFF</p>	<p>Step 2.</p>  <p>Learn ON signal Press button twice</p>	<p>Step 3.</p>  <p>Enters Learn mode for OFF code</p>	<p>Step 4.</p>  <p>Learn OFF signal Press button twice</p>	<p>Step 5.</p>  <p>Press to Exit</p>
--	---	---	---	--

Relay time settings

<p>0.5 Second</p>  <p>Garage door automation</p>	<p>1 Second</p>  <p>Gate & garage door automation</p>	<p>3 Seconds</p>  <p>Panic on alarm panel</p>	<p>Latch & Unlatch</p>  <p>Arming & Disarming alarm panels</p>	<p>3 Minute</p>  <p>Siren output or beam bypass</p>	<p>On / Off</p>  <p>Code 1 = ON Code 2 = OFF</p>
--	---	---	--	---	--

www.remotepro.com.au

WARNING

To prevent possible **SERIOUS INJURY** or **DEATH**:

- Battery is hazardous: **NEVER** allow children near batteries.
- If battery is swallowed, immediately notify a doctor.

To reduce risk of fire, explosion or chemical burn:

- Replace **ONLY** with the same size and type battery
 - **DO NOT** recharge, disassemble, heat above 100° C or incinerate
- Battery will cause **SEVERE** or **FATAL** injuries in 2 hours or less if swallowed or placed inside any part of the body.

